

## STRUCTURE AND SUPPORTS

## SUPPORT OF COLUMN

Glass plants and pipeline should be supported correctly. To prevent inducing undesirable stresses in the glass, support should be rigid. When supported, glass should be in compression.

Generally, glass plant and equipment are supported in a rectangular tubular structure. This structure is formed of galvenised mild steel tubing with the cast iron fittings which are described in this catalogue. This type of structure provides enough flexibility for future modifications and is strong enough to support a glass unit.

Following rules should be followed while supporting a glass unit in a tubular structure.

- The structure must be rigid. To give lateral support it must be braced back to the nearest wall
  or any rigid feature.
- All glass columns are build up from a fixed point on which whole weight of the column should be taken. If total loads exceeds the permissible limits, counter balance supports should be used to releive excessive weight.
- With change in temperature, glass column and tubular structure expands at different rate.
   Therefore glass unit must be free for vertical movement above the fixed point.
   Hence, above the fixed point, guides supports should be used to give lateral support.

